



Basic Project #2 architecture



Data & Status (only in Model) read



for status read
AO=1



Control Register write



(It is only enabled if CR.0 = 1)
(furthermore, INTR is only enabled if CR = 11)